


# Edifier

THE AUDIO ARTIST



## M1310

Multimedia Speaker

English

Français

## User Manual

---

Please read this manual carefully before operating the Speaker System

## Introduction

Congratulations on the purchase of the **Edifier M1310** speaker system. With the right care and attention, it will give you many years of trouble free operation.

Before operating the system, please read this manual fully to obtain the best results from your new product, and retain it carefully for future reference.

The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of un-insulated dangerous voltage within the product's enclosure that may be of a sufficient magnitude to constitute a risk of electric shock to persons.



**CAUTION: TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL ONLY.**

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

### SAFETY INSTRUCTIONS

Please read all the instructions herein.

Please retain this manual safely for future reference.

Please heed all safety warnings.

Please Install in accordance with the Manufacturer's instructions.

Please adjust the volume control to a comfortable level to avoid damaging your hearing and the system.

### WARNING:

#### TO REDUCE THE RISK OF ELECTRIC SHOCK:

Do not expose this apparatus to rain or moisture.

Do not use the speakers near water, and do not immerse them in any liquid or pour any liquid on them.

Do not block the openings in the speaker cabinets, never push objects into speaker vents or slots because of fire or electric shock hazards, and provide sufficient space around the speakers for proper ventilation.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Do not defeat the safety purpose of the polarized plug. A polarized plug has two blades with one wider than the other. The wider blade is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

For added protection during lightning storms, unplug the speakers from the electrical outlet and turn off the computer.

Unplug this apparatus when unused for long periods of time.

Heat---- Place the speakers away from all heat sources, such as heat registers, stoves, and direct sunlight.

Ventilation ---- Do not block the openings in the speaker cabinets, never push objects into speaker vents or slots because of fire or electric shock hazards, and provide sufficient space around the speakers for proper ventilation.

Location ---- Place the speakers in a stable location so that it will not fall causing damage to the speakers or bodily harm.

Cleaning --- Unplug the speakers from the computer and from the electrical outlet before cleaning them with a damp cloth.


Lightning ----For added protection during lightning storms, unplug the speakers from the electrical outlet and turn off the computer. Servicing is required when the apparatus has been damaged in any way, such as the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. Refer all servicing to qualified service personnel only.

## Opening the packing

Please check the speaker Model number marked on the packing carton. Please contact the seller as soon as possible if you find the speaker is the incorrect model or has sustained shipping damage.

### **M1310 packing list:**


- 1 x Subwoofer Speaker
- 2 x Satellite Speaker
- 1 x User Manual
- 1x Wired Controller




# Edifier

## Diagram and Function Description

1. **BASS** (Bass Volume Control)
2. **POWER** (Speaker Power Switch)  
“|” POWER ON  
“⏻” POWER OFF
3. **Power Cable**
4. **Line in** (Audio signal input)
5. **Speaker Output**
6. **Main Volume Control**
7. **Headphone Jack**
8. **Mute button**  
■ : PLAY  
■ : MUTE
9. **Speaker Status LED**  
LED ON : PLAY  
LED OFF : MUTE



Speaker Rear View



Wired Controller

## Speaker Connection Instructions

- Speaker Connection Instructions**


Please connect the left and right speaker to the rear Subwoofer panel as per the diagram.

- Computer Sound Card**

Please connect the Soundcard or another source to the input jack on the rear panel of the Subwoofer via the wired Volume Controller. Please refer to the diagram.

- Connection to AC Power Outlet**

Please connect the AC Power Plug to the correct AC Voltage for your area.



## Specifications

### Specifications:

Amplifier power output:

Satellite: RMS 8Wx2 (THD=10%, fo=1KHz)

Subwoofer: RMS 12W (THD=10%, fo=80Hz)

Signal to noise ratio (Amplifier):  $\geq 85$ dB

Amplifier distortion: THD+N<0.5%

Input Impedance: 10K Ohm

Input Sensitivity: 450mV. (+/- 50mV)

Volume Control: Wired Volume Control, Subwoofer built-in Bass Control.

Bass Unit: 5 inch (131mm), Magnetically Shielded, 4Ohm.

Satellite Unit: 3 inch (78mm) full range, Magnetically Shielded, 4Ohm.

Dimension: Subwoofer: 158(W)x200(H)x286(D) mm

Satellite: 95(W)x160(H)x108(D)mm

Weight: approx. 5.3kg

Power input: 100V-120V ~, 50/60Hz (for Model USA/Canada/Japan)

220V-240V ~, 50/60Hz (for Model European/China/Korea/South America, etc.)

### **Edifier One Year Limited Warranty**

Edifier warrants to the end user that all of its computer speaker systems are free from defects in materials and workmanship in the course of normal and reasonable use for a term of one year from the date of purchase.

This warranty is the exclusive and only warranty in effect relative to Edifier multimedia speaker systems and any other warranties, either expressed or implied, are invalid. Neither Edifier nor any authorized Edifier reseller is responsible for any incidental or consequential damages incurred in the use of the speakers. (This limitation of incidental or consequential damage is not applicable where prohibited.)

Edifier's obligation under this warranty does not apply to any defect, malfunction or failure as a result of misuse, abuse, improper installation, use with faulty or improper equipment, or the use of the speaker systems with any equipment for which they were not intended.

The terms of this warranty apply only to speaker systems when such speakers are returned to the respective authorized Edifier reseller where they were purchased.

Under the terms of this warranty, the original consumer purchaser has certain legal rights and may have other rights, which vary worldwide.

### **Notice**

Edifier and Edifier logo are owned by Edifier Enterprises Canada Inc., and may be registered. Other Brand names and trademarks are the property of their owners. Edifier assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

## Trouble Shooting Guide

- **Sound from only one Speaker.**

Please ensure all speaker cable connections are correct. Please try an alternate sound source such as a CD player, MP3 or other player. If both speakers now work correctly, the original sound source is at fault. Please ensure the computer Soundcard is installed correctly.

- **When playing CD from computer, only one Speaker has sound**

Mostly this phenomenon tends to occur with a new computer - only one satellite works when playing an audio CD, but all work correctly when running a WAV file or playing a Game. The reason for this is the CD-ROM is not matched with the Soundcard, or one signal channel maybe shorted to a ground wire. Also please refer to the CD-ROM user manual to adjust the jumpers.

- **No sound from any of the speakers**

1. Please ensure AC adapter is plugged and Power outlet is turn on.
2. Please ensure the Mute button on Wired Controller is set to OFF.
3. Please ensure all speaker audio cable connections are correct.
4. Please ensure sound source equipment output is working correctly.

- **Speakers exhibit excessive noise**

Edifier speakers are of a very low noise circuit design. Some source equipment may have a poor signal to noise ratio. Therefore, please unplug the input audio cable, and check if the noise is from the CD/DVD player or the Computer Soundcard etc.

- **Magnetically Shielded Speakers**

Edifier system subwoofers and satellite speakers are all of a magnetically shielded design. You can place the speakers near a TV or monitor. However, it is wise to allow a 0.2-1 m distance between the speakers and monitor to avoid possible magnetic field interference.

- **Listening Tips:**

All high quality speaker systems benefit from a running-in period on normal music sources to stabilize their intended properties.

- **To optimize the sound quality from your system:**

Sit in a comfortable position at the computer desktop. Take time to test the listening environment by using music CDs with wide frequency content and spacious left-to-right imaging. The speaker driver used in the loudspeakers will change their characteristics subtly over the first two weeks of use as the suspension of the cones will loosen up slightly, producing a trace more warmth to the overall sound texture. Adjust the speaker placement for the most realistic imaging and tonal balance by listening to several different musical selections and game or computer sound effects.

For optimum acoustic performance, we recommend that you place your speakers at least 6-8" from rear walls to reduce unwanted reflections that can muddy your sound. Bass frequencies may be enhanced or exaggerated by placing your speakers close to a wall or corner. Please feel free to experiment with the system's location to obtain the most pleasing effects.

Edifier couples incredible technology with an amplified loudspeaker system to generate smooth deep bass, crystal clear highs, and enough power to ensure that your personal listening experience allows you to hear what you have been missing!

- **If you have any further questions or concerns regarding Edifier Products**

please visit our website at: [www.edifier.com](http://www.edifier.com) ,

or email Edifier Support for further assistance at: [main@edifier.com](mailto:main@edifier.com) ,

If you prefer, you may contact us by phone Toll Free: 1-877-EDIFIER (334-3437).

Copyright© 2005  
All Rights Reserved.  
Manual Edition 1.1, Jun. 2005  
Printed in CHINA

**Edifier**

**[www.edifier.com](http://www.edifier.com)**

EDIFIER ENTERPRISES CANADA INC.

Made in China